


Locking and Powering Off



The power button on your device has many functions. **Press** the power button **once** to lock your device.

If your device is locked, **press** the power button **once** to bring the screen back on.



Press and hold on the power button to bring up power options, **power off** and **restart**.

If your device is **off**, **press and hold** the power button to turn it on.

Press the power button **twice quickly** to bring up your device's camera.